

◇施工時、主に必要な部材等◇





危険:製品の破損(割れ/欠け)を確認

搬入時に製品の破損(割れ/欠け)がないことを必ず確認してください。 検品していますが輸送時の破損がある可能性があります。



注意:施工前に「施工説明書」をよくお読みのうえ、正しく施工してください。 ここに示した内容は、状況によって重大な結果に結び付く可能性があ ります。いずれも、安全に関する重要な内容を記載していますので、 必ず守ってください。


※交換部品等の情報や、市品に関する最新情報は、ご購入いただきました販売店にお問い合わせください。

製品を設置する空間のクリアラン ホームページより型紙(テンブ スを確認してください。


レート) データをダウンロードし、 出力した型紙内の切り取り線 (cutout line) に沿って切り抜い てください。


穴を開けた型紙(テンプレート)を 天板 (カウンター) にのせ、開口穴 を写してください。写した開口穴に 沿って、ドリルやジグソーで開口し てください。


天板 (カウンター) の開口穴をきれ いにし、洗面器取付用金具を天板の 下部に仮付けしてください。




洗面器(ラバトリー)の縁 (リム)にコーキングを施し、 天板(カウンター)下部に仮 付けした、洗面取付金具で洗 面器(ラバトリー)を固定し









天板(カウンター)と洗面器(ラバ トリー) の隙間から出た不要なコー キングをクロス等できれいに取り除 いてください。


洗面器(ラバトリー)に水栓と 排水を設置してください。

水栓金具に止水栓、排水金具に 排水管(トラップ)を、それぞ れ接続してください。


止水栓を開けて通水し、水栓から の吐水が飛び散らないように止水 栓の開閉を調整してください。同 時に各接続部からの漏れがないこ とを確認してください。







危険:漏れのないこと 水漏れにより家財などをぬら す財産損害発生のおそれがあ ります。



修理および取付のご依頼は、KOHLER修理受付センターまで

受付時間/9:00~17:00 (土日祝日は除く)

TEL 0120-766-223 / FAX 050-3737-8779 http://www.s-mik.jp



KOHLER® 1 Year Limited Warranty

If a defect is found in normal residential use, Kohler Co. will, at it's election, repair, provide a replacement part or product, or make appropriate adjustment.

Damage to a product caused by accident, misuse, or abuse is not covered by this warranty. Improper care and cleaning will void the warranty.

Proof of purchase (original sales receipt) must be provided to Kohler Co. with all warranty claims Kohler Co. is not responsible for labor charges, installation, or other incidental or consequential costs.

In no event shall the liability of Kohler Co. exceed the purchase price of the faucet.

If the Faucet is used commercially or is installed outside of North America, or if the finish is gold, non-Vibrant or a painted or powder coated color finish, Kohler Co. warrants the Faucet to be free from defects in material and workmanship for 1 year from the date the product is installed, under Kohler Co.'s standard 1 year limited warranty.

If you believe that you have a warranty claim, contact Kohler Co., either through your Dealer, Plumbing Contractor, Home Center or E-tailer.

Please be sure to provide all pertinent information regarding your claim, including a complete description of the problem, the product, model number, color, finish, the date the product was purchased and from whom the product was purchased.

Also include your original invoice.

KOHLER CO. AND/OR SELLER ARE PROVIDING THESE WARRANTIES IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

KOHLER CO. AND/OR SELLER DISCLAIM ALL LIABILITY FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states/provinces do not allow limitations of how long an implied warranty lasts or the exclusion or limitation of such damages, so these limitations and exclusions may not apply to you.

This warranty gives the consumer specific legal rights.

You may also have other rights that vary from state/province to state/province.

This is Kohler Co.'s exclusive written warranty.

Trend® faucets, MasterShower® tower, BodySpa systems and components; WaterHaven® tower, systems and components; Tripoint® faucets, Polished Gold, non-Vibrant and painted or powder coated finishes, fittings; all items within the "Fixture Related" section of the Kohler Faucets Price Book, drains, Duostrainer® sink strainers, soap/lotion dispensers, Moxie™ Wireless Speaker; and faucets used in commercial settings, and outside North America, are covered by Kohler Co.'s one-year limited warranty.

Never use cleaners containing abrasive cleansers, ammonia, bleach, acids, waxes, alcohol, solvents or other products not recommended for chrome. This will void the warranty.....

修理および取付のご依頼は、KOHLER修理受付センターまで

受付時間/9:00~17:00 (土日祝日は除く)

TEL 0120-766-223 / FAX 050-3737-8779 http://www.s-mik.jp

1199847-2-A @ 2012 Kohler Co.